



## HR QAC QR TEST STRIPS

**CODE 2951HR**

1. Immerse pad in solution and remove immediately.
2. Hold strip level for 5 seconds. Shake off excess water from pad. Compare pad to color chart above.

**NOTE:**

- Sample must be at room temperature (above 75°).
- If testing Hyamine 1622, change dip time to 45 seconds in Step 1.
- Keep out of sunlight.
- Keep vial closed when not in use.



PO BOX 329 • CHESTERTOWN • MARYLAND • 21620  
410-778-3100

